


## Operating Schematic



## Product Size



PAGE: 01/02


## How to connect to APP?

### Step 01




### Step 02

Click+ add the device of remote controller that showing on the app



### Step 03

Click "DONE" you have completed the connection



### Step 04

Click into remote device A B C group can be added the lamp according to your required

